

Changing Dashboard Settings on the WebDAQ interface

When you change Dashboard settings while a job is running, the display updates to reflect the change. If the display is refreshed (by pressing F5 or clicking Reload, for example), the display updates with the settings configured for the job. This is because changes to Dashboard settings are not saved in the job descriptor when a schedule is running.

When the display is refreshed, Dashboard settings reset to what is defined in the job.

If you want Dashboard settings to be saved in the job descriptor and applied to all future acquisitions, configure Dashboard settings when the device is in an idle state.

Measurement Computing Data Acquisition Knowledgebase

<https://kb.mccdaq.com/KnowledgebaseArticle50789.aspx>