

## USB-CTR04 USB-CTR08 Measuring Frequency using CIn32

The following example demonstrates how to read frequency using a counter input and the MCCDAQ dot net API.

To access the API, add a reference to the MccDaq object. Adding the reference is usually accomplished by right clicking the Project [under the Project Explorer] and selecting Add Reference. The complete project is attached to the article and was created with Visual Studio 2008 using CSharp. Compiling and execution is quick as there is minimal Windows overhead and associated code.

To make the code more readable a few convenience functions were added such as IsError, GetBoardNum, and WaitForKey. The IsError function checks the error number in the ErrorInfo object and if not zero displays the error message. The GetBoardNum function begins reading the Device strings from each number location and as soon as it finds one that contains the identifying string it exits. The WaitForKey does just that - waits for someone to press a key. To view the complete program project download the attachment below.

Disclaimer:

The attached Code or Example is provided As Is. It has not been tested or validated as a product, for use in a deployed application or system, or for use in hazardous environments. You assume all risks for use of the Code or Example.

---

```
using System;
using MccDaq; // also, add reference to MccDaq to the project

namespace PeriodMode
{
    class Program
    {
        public const int          CHANCOUNT = 1;
        public const string       DEVICE = "USB-CTR"; //for USB-CTR04 or USB-CTR08
        public const int          CounterNum = 0;    //used to measure the signal
generator
        public const int          OutTimerNum = 0;   //used as signal generator
        public const CounterMode  Mode = CounterMode.Period;
        public const CounterDebounceTime  DebounceTime =
CounterDebounceTime.Debounce500ns;
        public const CounterDebounceMode  DebounceMode =
CounterDebounceMode.TriggerAfterStable;
        public const CounterEdgeDetection  EdgeDetection =
CounterEdgeDetection.RisingEdge;
        public const CounterTickSize      TickSize = CounterTickSize.Tick20pt83ns;    // 0
```





